

ASSEMBLY INSTRUCTIONS		AI 062
STOCKBRIDGE DAMPER		

1. Check the article number and the conductor range on the product with your conductor being used.



2. Place the Stockbridge damper over the conductor.

IMPORTANT:
The Stockbridge damper must be mounted with the weights towards the ground and the heavier weights directed to the span.

3. Tighten the bolt finger tight, so that the clamp shell can stiff be shifted on the conductor.



REV.	-	12-06-2012 / PAO	LANGUAGE	PAGE
	A	30-04-2025 / EUS		
			EN	1 of 2

ASSEMBLY INSTRUCTIONS	AI 062
STOCKBRIDGE DAMPER	

4. Check and make sure that the installation position (distance from the reference point) of the Stockbridge damper is according to the positioning of the relevant vibration damping study provided by PFISTERER.
5. Tighten the bolts by a torque wrench to the torque mentioned in the drawing and as marked on the product.



6. Secure the bolt by bending up the safety plate. Place the latter firmly against the surface of the hexagonal bolt head.



REV.	-	12-06-2012 / PAO		LANGUAGE	PAGE
	A	30-04-2025 / EUS		EN	2 of 2